



7. Level 2 Repair

7-1. Disassemble

1		2	
	1. Unscrew the screw in Rear(8 points) - SEC CODE : 6001-001811 , 1.4X3.0		1. Disassemble Rear
3		4	 1.Bracket+LCD module (LCD,Bracket can not be separated in normal condition)

7-2. assemble

1		2	
	1.Place on Bracket+LCD Module (LCD,Bracket can not be separated in normal condition)		1. Assemble LCD A'ssy Connector 2. Put Reciever in the hole
3		4	
	1. Assemble Rear 2. Push the Hook		1. Screw 10 points in Rear - SEC CODE : 6001-001811 , 1.4X3.0 - Torque : 1.1 ± 0.1 Kgf · cm